

This is a general guide, which may require modification to suit particular application requirements or specifications. For specific guidance on application contact LONG PRODUCTS, Technical Services Department.

SURFACE PREPARATION

The surface should be smooth and free from sharp projections and hollows. Cured concrete bases should be dry and swept free of dust and rubble. Internal and external angles require profiling prior to application.

PRIMER APPLICATION

Apply Longseal Membrane Primer, by brush, roller or spray, and allow to dry.

MEMBRANE APPLICATION

1. The release paper should be removed for the first 500mm of the roll and the membrane pressed firmly into position to ensure no air pockets are formed. Application of the roll is then completed by continuing to remove the release paper and smoothing the membrane on to the substrate.
2. Adjacent rolls should allow a minimum side overlap of 50mm and end overlap of 100mm on to the backing film. This overlap is in addition to any overlap on to the "zip strip edge." Prior to overlapping adjacent rolls, the release strip protecting the "zip strip edge" should be removed. Joints should be firmly pressed to ensure a watertight seal.
3. On internal or external angles or corners a reinforcing strip should be applied.
4. Membrane should always be laid across the falls.
5. After application, to ensure the membrane is not damaged during backfilling or by following trades, a screed, protection board, or similar protection, should be laid immediately

Tel. 0044 (0)1797 223561, Fax 0044 (0)1797 224530

Email: info@longproducts.co.uk